


## EXHAUST GAS TEMPERATURE / EXHAUST GAS TEMPERATURE GAUGE

### Illustration of Instrument Connection:



### NOTE:

- 1) When installing the instrument from behind the panel, use a 2 1/4 " (57mm) hole. Use 4 #40 screws to hold instrument secure. When installing the unit from in front of the panel, use a 2 1/16 " (52mm) hole.
- 2) Mount at least 12 " away from compass.
- 3) This unit has not been approved for type certified aircraft.