

## BRP-Rotax ILLUSTRATED PARTS CATALOG

### REPAIR TOOLS

#### NOTE

*All Repair tools are non-certified parts.*




Figure 1.3: Repair tools

ITEM NO.	APPLICATION	ITEM NO.	APPLICATION
1-4	Roller bearing 25x25x15, oil seal 30x52x7	13	Ball bearing 15x32x8 - governor drive
5	Crankshaft locking screw M8x50	14	Ring wrench 10/13
6	Gearbox	15	Fixture for governor drive
7	Crankshaft (magneto side)	16	Ball bearing 15x32x8, needle sleeve - governor drive
8-11	Ball bearing 15x32x8 - oil inlet flange, oil inlet cover	17	Oil seal 22x32x7 - governor drive
12	Needle bearing 22x28x12 - governor drive		