

BRP-Rotax ILLUSTRATED PARTS CATALOG




Figure 1.7: Repair tools

ITEM NO.	APPLICATION	ITEM NO.	APPLICATION
43	Crankcase	49	Trestle support
44-45	Dial gauge	50	Thread bent socket
46	Dial gauge adapter for valve seat inspect	51	Oil filter
47	Crankcase	52	Twist of crankshaft
48	Engine removal	53	ECU (Engine Control Unit)